



112000
ZOCOLO ANTISCIVOLO CE
35 • 36 • 37 • 38 • 39 • 40
41 • 42 • 43 • 44 • 45 • 46 • 47



112010
ZOCOLO DONNA LIGHT
35 • 36 • 37 • 38 • 39 • 40



112020
ZOCOLO UOMO LIGHT
41 • 42 • 43 • 44 • 45 • 46 • 47



112050
ZOCOLO CON PUNTALE BIANCO
35 • 36 • 37 • 38 • 39 • 40
41 • 42 • 43 • 44 • 45 • 46 • 47



112051
ZOCOLO CON PUNTALE NERO
35 • 36 • 37 • 38 • 39 • 40
41 • 42 • 43 • 44 • 45 • 46 • 47



112600
ZOCOLO AUTOCLAVABILE BIANCO
[34-35] • [36-37] • [38-39]
[40-41] • [42-43] • [44-45] • [46-47]



112601
ZOCOLO AUTOCLAVABILE NERO
[34-35] • [36-37] • [38-39]
[40-41] • [42-43] • [44-45] • [46-47]



112604
ZOCOLO AUTOCLAVABILE VERDE
[34-35] • [36-37] • [38-39]
[40-41] • [42-43] • [44-45] • [46-47]



112606
ZOCOLO AUTOCLAVABILE BLU
[34-35] • [36-37] • [38-39]
[40-41] • [42-43] • [44-45] • [46-47]





112100
SCARPA SENZA LACCI BIANCO
35 • 36 • 37 • 38 • 39 • 40
41 • 42 • 43 • 44 • 45 • 46 • 47



112400
SCARPA SENZA LACCI NERO
35 • 36 • 37 • 38 • 39 • 40
41 • 42 • 43 • 44 • 45 • 46 • 47



112200
SCARPA CON LACCI BIANCO
35 • 36 • 37 • 38 • 39 • 40
41 • 42 • 43 • 44 • 45 • 46 • 47



112201
SCARPA CON LACCI NERO
35 • 36 • 37 • 38 • 39 • 40
41 • 42 • 43 • 44 • 45 • 46 • 47



112311
SCARPA DONNA ANTISCIVOLO NERO
35 • 36 • 37 • 38 • 39 • 40 • 41



112211
SCARPA DONNA CON LACCI
35 • 36 • 37 • 38 • 39 • 40 • 41



112301
SCARPA DIRECTOR NERO
38 • 39 • 40 • 41 • 42 • 43 • 44 • 45 • 46 • 47

